


LOCINOX[®]


Let's make better fences together

RHINO


① Package content




② 180° mounting




③ Dimensions & drilling template




④ Left or right mounting



⑤ Cover gear installation



6 Cover gear installation




HEX
4 mm

7 Gate type installation situations


	A		B	
	mm	feet	mm	feet
M16	≥ 42 mm	≥ 1-5/8"	≥ 52,5 mm	≥ 2-1/16"
1034ROLL-HDG-M16	≥ 43 mm	≥ 1-11/16"	≥ 53 mm	≥ 2-1/16"
M20	≥ 46 mm	≥ 1-13/16"	≥ 62 mm	≥ 2-7/16"
1034ROLL-HDG-M20	≥ 49 mm	≥ 1-15/16"	≥ 65 mm	≥ 2-9/16"

8 Removing pre-tension fixer




HEX
3 mm
5 mm

9 Adjusting speed




HEX
3 mm

10 Adjusting final snap



HEX
3 mm

11 Finalising installation



LOCINOX[®]
WWW.LOCINOX.COM

Doc. Nr.: MANU-000250

Locinox nv • Mannebeekstraat 21 • B-8790 Waregem • Belgium
Tel. +32 (0)56 77 27 66 • Fax. +32 (0)56 77 69 26 • E-mail: locinox@locinox.com



* M A N U - 0 0 2 5 0 *